## Operating Procedure – Multi I-V Curve Tracer (Daystar)



National Centre for Photovoltaic Research and Education (NCPRE)

Indian Institute of Technology- Bombay

Powai, Mumbai-400076

INDIA

## **Standard Operating Procedure**

- 1. Make sure the AC is set to 24 °C.
- 2. Connect the PV module and temperature sensors with the respective load unit and control unit.
- NCPRE

- 3. Make sure the cables are correctly connected.
- 4. For accessing/downloading the data, download the FileZilla software and connect to the respective IP address.

**End of Document**